

INDIKATORI TEMPERATURE

PRIMENA

Merenje temperature hladnjaka.

TEHNI KI PODACI

Spoljnja temperatura: od -40 do +130 °C
Merni opseg: od -40 do +120 °C
Greška merenja: $\pm 10\%$

Tip 433.46.011



Tip 433.46.012 ŠINVOZ



Tip 433.46.022 Ikarbus



Tip 433.42.22 Famos



Tip 433.46.312 Torp.




Tip 433.46.42 IMT



Tip 433.36.021



ŠEMA POVEZIVANJA



indikator

senzor

A.D. INSA - INDUSTRIJA SATOVA

Trš anska 21
11080 Beograd - Zemun
Republika Srbija




www.insa.rs



+ 381 (11) 2612 - 422
+ 381 (11) 3713 - 606
+ 381 (11) 3173 - 607
+ 381 (11) 2614 - 330


Fax:

E-mail: office@insa.rs
info@insa.rs

INDIKATORI TEMPERATURE

A Kontakt za osvetljenje

B 2 L-drža a



D mera temperature

E priključak A6.3x0.8, DIN46244

A.D. INSA - INDUSTRIJA SATOVA

Tršanska 21
11080 Beograd - Zemun
Republika Srbija



www.insa.rs



+ 381 (11) 2612 - 422
+ 381 (11) 3713 - 606
+ 381 (11) 3173 - 607
+ 381 (11) 2614 - 330

Fax:

E-mail: office@insa.rs
info@insa.rs